

Top Ten Things You and Your Student Should Know About the Braille Sense Plus QWERTY

NOTE: This worksheet is intended to be used with the Introduction to the Braille Sense Plus QWERTY training. The audio for the training can be found at www.gwmicro.com/bsq. Then, click on the link called Online Training Session 1.

1. You can turn on the key describer by pressing Ctrl-Esc.
2. You can adjust the voice with the following keystrokes:
 - a. SHIFT-F6 will decrease the volume. F6 will increase the volume.
 - b. SHIFT-F7 will decrease the rate. F7 will increase the rate.
 - c. SHIFT-F8 will decrease the tone. F8 will increase the tone.
3. You can toggle between Computer Braille, Contracted Braille, and Uncontracted Braille by pressing Function-G.
4. You can access the Program menu at any time by pressing the WINDOWS KEY.
5. If you are in an application, and you want to access the menu for that application, pressing ALT will open the menu.
6. You can access the Options menu at any time by pressing WINDOWS-O or F10.
 - a. Once in the Options menu, you can change any of the options by pressing SPACE or BACKSPACE.
 - b. You must press ENTER in the Options menu to save the changes.
7. To open an application, press ENTER on it.
8. When in the File Manager, press ENTER on a drive to open it. To get out of the list of folders in the drive, press BACKSPACE.
9. You can toggle the voice on or off by pressing F5.
10. You can toggle the Braille display on or off by pressing F4.